

FIT Harvest Supported Monitors (Page 1)

Quick Reference Guide

<p><u>Ag Leader InSight</u></p> <p>This system is a touch screen monitor that logs data to a Compact flash card.</p> <p>A Compact Flash Card Adaptor is needed to insert the card into your laptop and for FIT to recognize the card.</p> <p>File Format: .ILF</p>		<p><u>Ag Leader EDGE</u></p> <p>Entry-level monitor 6.5-inch color touchscreen that logs data to a Compact flash card.</p> <p>A Compact Flash Card Adaptor is needed to insert the card into your laptop and for FIT to recognize the card.</p> <p>File Format: .ILF</p>	
<p><u>Ag Leader PF Advantage</u></p> <p>This system is operated by buttons to log data to a ATA Flash memory card.</p> <p>No Card adaptor is needed.</p> <p>File Format: .yld</p>		<p><u>GreenStar 2 (GS2) (2600)</u></p> <p>This system is a touch screen monitor that logs data to a Compact Flash Card.</p> <p>A Compact Flash Card Adaptor is needed to insert the card into your laptop and for FIT to recognize the card.</p> <p>File Format: All the files are in the RCD Folder.</p>	
<p><u>Ag Leader PF3000 or (Pro)</u></p> <p>This system logs data to an ATA Flash memory card.</p> <p>No Card adaptor is needed.</p> <p>File Format: .yld</p>			
<p><u>Ag Leader YM2000</u></p> <p>Memory Card Slot requires a 1-4 meg SRAM Card. Due to limited storage capacity size of this card it requires downloading after 25-30 hours.</p> <p>No Card adaptor is needed.</p> <p>File Format: .yld</p>		<p><u>GreenStar (GS1) (Original GreenStar)</u></p> <p>This system consists of three components; the GreenStar display, the mobile processor and the star fire receiver.</p> <p>File Format: All the files are in the PFData Folder.</p> <p>Note: GS1 system has two cards side by side. One card is the key card (program) and the other card is the data card.</p>	

FIT Harvest Supported Monitors (Page 2)



Quick Reference Guide

CASE AFS 600 (Voyager 2)

This system is a touch screen monitor that logs data to a compact flash card or a standard ATA Flash Card (pcmcia) sized from 32mb to 512 mb.

If using a Compact Flash Card, then an adaptor is needed to insert the card into your computer and for FIT to recognize the card.

File Format: .cn1



or

Case AFS – Black Box

Memory Card Slot requires a 1-4 meg SRAM Card. Due to limited storage capacity size of this card it requires downloading after 25-30 hours of harvest.

File Format: yld



M 119199



Case IH Universal Display

Case IH Universal Display Plus

This system must use a 32 meg Compact Flash Card (with Adaptor) only.

File format is .vyg




AGCO FieldStar 2

This system is a touch screen monitor that logs data to a SD card.

Memory Card: Uses a SD Card. A SD Card Adaptor is needed to insert the card into your computer and for FIT to recognize the card.

Available on AGCO Challenger

File Format: xml and bins (all the files are located in the Task Data folder).



SD Card Adapter

Case AFS – B/W Touch Screen

This system must use a 32 meg Compact Flash Card (with Adaptor) only.

File format is .vyg



AGCO FieldStar 1

Memory Card: Requires a very expensive card reader called Omnidrive. Therefore, contact Brenda Hoyt to make arrangements to swap data cards (we send you a blank data card and you send customers data card).

File Format: .fsb (only seen with Card Reader)



Card Swap